

# Schoch Harley-Davidson

## Service Department

## Softail Models

### Vehicle Maintenance Schedule

Item Serviced	Procedure	1,000	2,500	10,000	20,000	25,000	DONE
		5,000	7,500	30,000	40,000	50,000	
Engine Oil & Filter	Replace or Inspect Level	R	I	R	R	R	
Oil Lines & Brake Lines	Inspect for leaks	I	I	I	I	I	
Air Cleaner	Inspect and Clean	I	I	R	R	I/R	
Tires	Inspect Tread, Check Pressure	I	I	I	I	I	
Wheel Spokes	Check Tightness	C/A	C/A	C/A	C/A	C/A	
Primary Chaincase Fluid	Replace or Inspect Level	R	I	R	R	R	
Primary Chain	Adjust (N/A For 2007 Up)	A		A	A	A	
Transmission fluid	Replace or Inspect Level	R	I	R	R	R	
Clutch	Adjust	A		A	A	A	
Clutch Cable	Adjust and Lubricate	A/L	I	A/L	A/L	A/L	
Cam Chain Tensioners	<b>Inspect or replace at 35K</b>						
Rear Belt and Sprockets	Inspect, Adjust Belt	I/A	I	I/A	I/A	I/A	
Throttle and Enrichner Cables	Adjust and Lubricate	A/L	I	A/L	A/L	A/L	
Clutch and Brake Lever Pins	Lubricate	L		L	L	L	
Kick Stand	Lubricate	L	L	L	L	L	
Fuel Valve, Lines and Fittings	Inspect for Leaks	I	I	I	I	I	
Fuel Tank Filter Screen	Replace (25K + 50K)					R	
Brake Fluids	Check Levels and Condition	I	I	R	R	R	
Brake Pads and Discs	Inspect for Wear	I	I	I	I	I	
Brake Components: Caliper Pins, Boots, Bushings	Inspect	I	I	I	I	I	
Shifter Linkage	Inspect and Lubricate	I/L	I	I/L	I/L	I/L	
Spark Plugs	Inspect or Replace	I	I	R	R	I/R	
Electrical Equipment	Check Operation	C	C	C	C	C	
Electrical Switches	Check Operation	C	C	C	C	C	
Electrical Diagnostic Check	Digital Technician Computer			V	V	V	
<b>All EFI Vehicles Will Receive a Printout Using our Digital Technician Computer Verifying Proper Operation at 10K's</b>							
Engine Idle Speeds	Check and Adjustment	V	V	V	V	V	
Front Fork Oil	Replace				R		
Steering Head Bearings -	Adjust/ Lubricate- <b>replace at 50K</b>	A/L		A/L	A/L	A/L/R	
Windshield Bushings	Inspect	I	I	I	I	I	
Exhaust System	Check All Fasteners	C	C	C	C	C	
Critical Fasteners	Check Tightness	C	C	C	C	C	
Battery	Verify Charging and Connectio	V	V	V	V	V	
Road Test	Verify Operation of All Componen	V	V	V	V	V	
<b>SPRINGER MODELS</b>							
Steering Head Bearings -	Adjust and Lubricate	A/L		A/L	A/L/R	A/L/R	
Front End Rocker Bearings	Disassemble and Adjust	D/A		D/A	D/A	D/A	
Wash	Hot & Soapy with Air Blow Dry	W	W	W	W	W	

D = Disassemble  
 C = Check  
 V = Verify  
 A=Adjust  
 R = Replace  
 I = Inspect  
 L = Lubricate  
 W = Wash